

6" EXTREME MITER INSTRUCTIONS

1. MARK OUTSIDE OF GUTTER WITH THE DOTTED LINE SHOWN IN THE DRAWING
2. CUT ALONG THIS LINE
3. MAKE RELIEF CUT
4. FOLD TAB
5. INSERT GUTTER 4-7/8" FROM THE INSIDE CORNER OF THE MITER
6. FASTEN BACK ONLY
7. COMPLETE INSTALLATION OF THE GUTTER
8. INSTALL MATING GUTTER SECTION
9. COMPLETE INSTALLATION OF THE MATING GUTTER
10. FASTEN AND SEAL INSIDE OF MITER



