


We recommend packing elbow 1/2" above sd. this will minimize damaging elbow & ext. during lawn maintenance

Install cloth tab to extension first then raise ext. & attach vinyl tab to downspout in + form.

(DO NOT INSTALL)

Create these notches with a tin snips or miter saw on the extension, by removing 3" from the top wall as shown below.



IMPORTANT
SIDE WALLS OF THE EXTENSION
NEED TO BE FLARED OUT TO KEEP
FROM CATCHING ELBOW WHEN
LOWERED

